



Gressco

MAGNETIC SAND TABLE

Maintenance Instructions

Cleaning the glass and acrylic

Acrylic- Use any commercially available plastic cleaner that has been approved for Plexiglas following the instructions on the container. While minor scratches are inevitable with acrylic and have no effect on the “play value”, scratches may be removed with potions made for that purpose readily available from plastic supply or hardware stores.

Tempered Safety Glass – Use any commercially available glass cleaner.

Static Stuck Stand - In particularly dry areas, sand may stick to the inside of the top. This condition caused by static electricity is not permanent. The static will dissipate by itself within a day or two.

Cleaning the wood frame

Treat the Magnetic Sand Table frame as you would any fine wood furniture. It may be wiped down with most commercial cleansers or dusting agents applied sparingly on a damp, soft cloth. Do not allow any part of the frame to soak in liquid for more than a few minutes.

328 Moravian Valley Road, P.O. box 339, Waunakee WI 53597
Toll Free 800-345-3480, Phone: 608-849-6300, Fax 608-849-6304
www.gressco.com email: info@gresscoltd.com